



instadose - FAQ's

How does it work?

Instadose allows users to have the flexibility to view their radiation dose at any time from any computer with internet access. Readings via a PC are enabled by a USB compatible detector. Once a user receives instadose they must first register at: www.instadose.com. During the registration process the instadose driver and client are installed on the users' computer and the device is initialized for use.

When a user wishes to obtain a reading they simply log-in to their account, plug-in instadose to a USB port and on the homepage click on the computer image with the message "Plug in your instadose device now and click here to get an instant reading". The accumulated dose stored on instadose is processed through a proprietary algorithm. This fully automated transfer of data minimizes the chance of human error and misidentification. Once complete a graphical representation of the current dose will load on the screen. Users can also view their cumulative dose level by clicking "View Cumulative Dose."

A variety of reports are available for download through AMP (Account Management Program)." The reports include:

- Radiation Exposure Summary Report
- History Detail Report
- Who Has Not Read Their Device

What is AMP?

AMP (Account Management Program) is Quantum Products' solution to providing customers with secure online account management. It's fast, simple, and free!

With AMP, account administrators can manage all the elements of a radiation monitoring program online anytime, from anywhere. From account administration to managing individual wearers and devices, AMP will give you real time access to account details, device assignments, reports, and all your pertinent account information.

AMP restricts users within an account from seeing other wearers' data and from making changes to the main account. The account administrator assigns each instadose™ device to a specific user. Each device has an embedded unique serial code that gets assigned to an individual user.

A few of the functions that are accessible by the account administrator include:

Main Account Information

- Contact information
- Company information
- Change password
- View orders
- Add administrator

Manage Locations - Separate and track badges for each department in a facility or for offices in other regions with options to manage locations:

- Details of the badges in the location
- Report information
- Add/delete/Reinstate locations

Manage Wearers - Administrators can view user data by location or perform individual searches:

- Add
- Edit/ delete
- Transfer
- Reinstate

Devices - Administrators can perform the following functions with each instadose device within their account:

- Buy a new device
- Edit/Cancel
- Reinstate
- Reassign
- Replacement device

Reports Section - Administrators can select from various types of reports and view the reports for each user within their account:

- Review who has not read their device (last 30 days available only)
- Radiation Exposure Summary Report
- History Detail Report
- Who Has Not Read Their Device

Once an administrator sets-up a user within their account, a user can log into AMP and get real-time readings by inserting their assigned device into a USB port on any internet-connected PC.

Users will have access to the following areas within AMP:

Log-In Information:

- Change account password

Report Section- Users can view various types of reports about their own dosage history:

- Radiation Exposure Summary Report
- Total Dose Report
- History Detail Report

Who needs Instadose?

Federal and State regulations limit the amount of radiation that workers are allowed to receive. Radiation monitoring should be considered for those who work in occupations where risks may be prevalent due to exposures from X-ray equipment or in labs where radioactive materials are utilized. Constantly measuring radiation dose with instadose, is a great way to show your employees you care about their health and safety. Instadose is NVLAP accredited and is in compliance with ANSI HPS N13.11 2001 through performance testing.

How often should Instadose be read?

As part of a good As Low As Reasonably Achievable (ALARA) program it is recommended devices be read once a week. Using the principles of ALARA means doing everything you can to minimize the affects of radiation to yourself and your patients.

What does it cost?

Quantum Products offers flexible subscription plans for your convenience:

- Best Buy - This annual subscription plan includes unlimited reads.
- Pick and Go - This 3-month subscription plan is payable at the beginning of each quarter.

Both subscriptions include access to our real-time streaming news that is tailored to your industry. Quantity discounts are available on both plans for accounts with over 20 users. Please contact us to obtain pricing information. Subscriptions will be automatically renewed and charged upon expiration.

Is there a set-up fee?

We do not charge set-up, annual maintenance or administrative fees.

Does the device need to be shipped back to receive a record of dose?

No, on AMP you can access Radiation Exposure Summary Reports under the report section.

How Do I Get Started?

Call LAURUS Systems at (410) 465-5558 or follow the link at <http://www.LAURUSSystems.com>
Refer to Code # D054 When Ordering instadose!

