

Direct Read Dosimeter Charger

Charger

The patented, handheld CHARGER can charge a variety of direct-reading dosimeters by simply squeezing the lever of a generator. The Charger requires no batteries. By pulling a trigger, a dosimeter is easily placed in or removed from the charger. The clamping action holds the dosimeter for you.

Includes:
1 year limited warranty



Specifications:

Power:	15,000Volt Piezoelectric generator
Discharge Bulb:	Flashes to indicate instrument is operational
Clamping Mechanism:	Adjustable and self locking. Spring loaded-applies 10 lbs of pressure. All metal parts are stainless steel
Temperature Range:	Operating: -20°C to +50°C (-4°F to + 122°F)
Humidity Range:	0 to 90% Relative humidity
Weight:	245.1 grams (8.64 oz)
Size:	152.4 x 107.95 (at its widest point) x 22.22 mm (6x4.2x.87 inches)

THE VersaBrite LITE

**AVAILABLE FOR ILLUMINATION OF
THE DIRECT-READ DOSIMETER**

