

# METOR 28

## Handheld Metal Detector



*baggage & parcel*

*inspection  
technology*



Hand-held metal detectors are an integral part of the physical security screening process. With the Metor 28, we have designed a unit that benefits security personnel as well as the person being scanned. Our unique angled design allows you to thoroughly scan an individual, while keeping your hand away from their body.

### Additional Benefits

- The circular opening assists in pinpointing metal objects
- Comfortable handle for easy control and grip
- Lightweight 260 g (9.3 oz.) with battery
- Wrist strap

### Detection

Detects all metals, both ferrous and non-ferrous.

### Sensitivity

Three (3) sensitivity settings

Detection performance:

- Level 1: small handguns and knives
- Level 2: razor blades, handcuff keys
- Level 3: .22 caliber bullet, metal shanks

### Operation

3-way push-button operation:  
On/Off/Momentary.

### Battery

NiMH rechargeable battery or 9V alkaline battery.  
Low battery indicator, both visual and audible.

### Alarm

Audible and visual alarm indication.

### Rugged Construction

High impact resistant ABS case.



### Safety

The Metor 28 is safe for people with pacemakers and will not affect magnetic recording media. The magnetic field strength of the Metor 28 meets with the limits set by international standards for human safety.

### Conformity

Safety Standards: Conforms with applicable EU directives, CE Compliant

### Specifications

Power:	Standard 9V battery or rechargeable NiMH battery
Battery Life:	Alkaline battery 120 h Rechargeable NiMH battery (170 mAh) 40 h* Recharge time for NiMH battery (170 mAh) 12 h*
Weight:	9.3 oz. (260 g) with battery
Dimensions:	Body - 16.35 x 5.5 in (410 x 140mm) Grip - 1.3 x 1.3 in (33 x 33mm)
Warranty:	Two (2) Year
Options:	Charging unit

